

Timber Conversions

Lineal Meters to Cubic Meters

- Lineal Metres x Nominal Width x Nominal Depth = Cubic Metres

Eg: 200 lm of 90 x 45 = 200 x .09 x .045=0.81 m³

Square Metres to Lineal Metres - Decking

- Sq Metres / Board Width plus gap (3mm) + Waste Factor = Lineal Metres

Eg: 140 m² of 90 x 19 Decking = 140 / 0.093 = 1505 lm + waste factor

Square Meters to Lineal Metres – Weatherboards

- Sq Metres / Board Coverage + Waste Factor

Eg: 140 m² of 150 x 25 Rusticated WB = 140 / .110 = 1272 lm + waste factor

Weatherboard	Measurement	Board Coverage
Rusticated weatherboard	150 x 25	110mm
Rusticated weatherboard	200 x 25	155mm
Bevelback Weatherboard	200 x 25 (180 x 18)	148mm
Bevelback Weatherboard	150 x 25 (135 x 18)	103mm

Imperial (Inches)	Rough Sawn	Machine Gauged
2 x 2	50 x 50	45 x 45
3 x 2	75 x 50	70 x 45
4 x 2	100 x 50	90 x 45
6 x 2	150 x 50	140 x 45
8 x 2	200 x 50	190 x 45
10 x 2	250 x 50	240 x 45
12 x 2	300 x 50	290 x 45
3 x 3	75 x 75	70 x 70
4 x 3	100 x 75	90 x 70
6 x 3	150 x 75	140 x 70
8 x 3	200 x 75	190 x 70
10 x 3	250 x 75	240 x 70
12 x 3	300 x 75	290 x 70
4 x 4	100 x 100	90 x 90
6 x 4	150 x 100	140 x 90
8 x 4	200 x 100	190 x 90
10 x 4	250 x 100	240 x 90
12 x 4	300 x 100	290 x 90
	100x25	90x19
	150x25	140x19